

VS-87

Double Switch - 33218-000
Single Switch - 57317-000
Wall Plate - 35887-000

VS-88

Fan Switch- 26542-000
Wall Plate - 89522-000
Knob - 12405-000
Double Switch- 33218-000

VS-89

Wall Plate - 89473-000 (K6083)
Switch - 85228-000 (K6081)

HS-92S

Wall Plate - K3227-000
Double Switch - K3149-000

HS-92SN

Wall Plate - 89481-000 (K6192)
Double Switch - 85921-000 (K6206)