


EFFECTIVE DATE

May 1, 1971

NuTone PARTS LIST

MODEL
VS-68 & VS-69
HEATERS



REF.	PART NO.	*Part used on other model/s	PART DESCRIPTION
<u>MODEL VS-68</u>			
1	23457		Time Switch Complete
2	21432	*	Toggle Switch
3	27429	*	Mounting Strap
4	12420	*	Time Switch
5	23461		Dial Plate
6	69073		Knob
<u>MODEL VS-69</u>			
1	23458		Time Switch Complete
2	12420	*	Time Switch only
3	21432	*	Toggle Switch - 2 required
4	27429		Mounting Strap
5	23462		Dial Plate
6	69073		Knob

Order Parts From: PARTS DEPT. C/O

NuTone (SCOVILL)