

Remote Door Control

MODEL: 499

LOCATION

The Model 499 Postal Lock Door Control should be installed as close to the door being controlled as possible.

The unit requires a 3 $\frac{1}{8}$ " x 4 $\frac{3}{4}$ " cut-out. It may be mounted either vertically or horizontally (check with local post office for their regulations). (Figure 1).

SYSTEM WIRING

A pair of wires should be run to the rough opening from the "Postal Lock" terminals on the Model 478 Control Amplifier. For a more detailed review of System wiring, refer to Model 478 Installation Instructions (Part No. 47135).

MOUNT THE HOUSING

Place the control housing in the cut-out opening, and mark the location of the two mounting holes with a pencil. Remove housing and drill pilot holes at marked points at about a 45° angle (See Figure 1). If you are drilling into wood, use a $\frac{1}{8}$ " bit; if you are drilling into plaster or plasterboard, use a $\frac{1}{4}$ " bit. Press expansion shields into pilot holes in plaster or plasterboard.

Bring Postal Lock wires through hole in rear of housing, and fasten housing in opening with screws shield.

INSTALL PUSH BUTTON

Fasten Postal Lock wires to terminals on back of Model PB-12 push button, supplied. Remote Door Control may also be used without push button to hold a door key. Fasten push button to rear wall of housing box with screws supplied with push button. (Figure 2).

POSTAL LOCK

The Postal Lock is supplied and installed by your local post office. Place the 4 10-32 x $\frac{7}{8}$ " phillips-head screws in Remote Door Control for mounting of postal lock.





Fig.1




Fig.2

NuTone®

Two Year Limited Warranty

WARRANTY OWNER: NuTone warrants to the original consumer purchaser of its products that such products will be free from defects in materials or workmanship for a period of two (2) years from the date of original purchase. **THERE ARE NO OTHER WARRANTIES, EXPRESS OR IMPLIED, INCLUDING, BUT NOT LIMITED TO, IMPLIED WARRANTIES OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE.**

During this two year period, NuTone will, at its option, repair or replace, without charge, any product or part which is found to be defective under normal use and service. **THIS WARRANTY DOES NOT EXTEND TO FLUORESCENT LAMP STARTERS OR TUBES, FILTERS, DUCT, ROOF CAPS, WALL CAPS AND OTHER ACCESSORIES FOR DUCTING.** This warranty does not cover (a) normal maintenance and service or (b) any products or parts which have been subject to misuse, negligence, accident, improper maintenance or repair (other than by NuTone), faulty installation or installation contrary to recommended installation instructions.

The duration of any implied warranty is limited to the one year period as specified for the express warranty. Some states do not allow limitation on how long an implied warranty lasts, so the above limitation may not apply to you.

NUTONE'S OBLIGATION TO REPAIR OR REPLACE, AT NUTONE'S OPTION, SHALL BE THE PURCHASER'S SOLE AND EXCLUSIVE REMEDY UNDER THIS WARRANTY. NUTONE SHALL NOT BE LIABLE FOR INCIDENTAL, CONSEQUENTIAL OR SPECIAL DAMAGES ARISING OUT OF OR IN CONNECTION WITH PRODUCT USE OR PERFORMANCE. Some states do not allow the exclusion or limitation of incidental or consequential damages, so the above limitation or exclusion may not apply to you. This warranty gives you specific legal rights, and you may also have other rights, which vary from state to state. This warranty supersedes all prior warranties.

WARRANTY SERVICE: To qualify for warranty service, you must (a) notify NuTone at the address stated below or telephone 1/800-543-8687, (b) give the model number and part identification and (c) describe the nature of any defect in the product or part. At the time of requesting warranty service, you must present evidence of the original purchase date.

Date of Installation

Builder or Installer

Model No. and Product Description

IF YOU NEED ASSISTANCE OR SERVICE:

For the location of your nearest NuTone Independent Authorized Service Center:

Residents of the contiguous United States Dial Free 1-800-543-8687

Please be prepared to provide:

Product model number • Date and Proof of purchase • The nature of the difficulty

Residents of Alaska or Hawaii should write to: NuTone Inc. Attn: Department of National Field Service, 4820 Red Bank Road, Cincinnati Ohio 45227-1599.

Residents of Canada should write to: Broan-NuTone Canada, 1140 Tristar Drive, Mississauga, Ontario, Canada L5T 1H9.

Rev. 03/2001

Product specifications subject to change without notice.

NuTone®

4820 Red Bank Road, Cincinnati, Ohio 45227
Printed in U.S.A., Rev. 5/2001, Part No. 47218